
## **USER MANUAL QUARTZ** | VH61 Quartz Movement

#### INTERNATIONAL WARRANTY

UNDONE, will within one year from date of purchase repair or replace the watch movement if it has a manufacturing defect. The International Warranty does not cover theft, loss or consequences of natural disasters, damage resulting from accidents (shocks, knocks, dents, etc.), alteration or damage resulting from unauthorized servicing, mistreatment or improper use. In order to be valid, the warranty card must be presented being fully completed and signed by an approved UNDONE dealer.

Thank you for supporting us in democratizing custom made timepieces.

Register to become an Undone member to receive our latest news and exclusive offers.



# **Setting the Time**

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown clockwise to set time.
- Push the crown back to position 1. 1.3

## **Quick Correction Of Date**

- Pull the crown to position 2.
- 2.2 Turn the crown counter-clockwise to set date.
- 2.3 Push the crown back to position 1.


### **USER MANUAL QUARTZ** | VH31 Quartz Movement

#### INTERNATIONAL WARRANTY

UNDONE, will within one year from date of purchase repair or replace the watch movement if it has a manufacturing defect. The International Warranty does not cover theft, loss or consequences of natural disasters, damage resulting from accidents (shocks, knocks, dents, etc.), alteration or damage resulting from unauthorized servicing, mistreatment or improper use. In order to be valid, the warranty card must be presented being fully completed and signed by an approved UNDONE dealer.

Thank you for supporting us in democratizing custom made timepieces.

Register to become an Undone member to receive our latest news and exclusive offers.



# **Setting the Time**

- 1.1 Pull the crown to position 2.
- 1.2 Turn the crown clockwise to set time.
- Push the crown back to position 1. 1.3